



586-239-8389
info@yourboardwrap.com

EASY APPLICATION INSTRUCTIONS

Installation Video: www.yourboardwrap.com/snowboardwrapinstall.html

Materials & Tools Needed before installing YourBoardWrap

- Denatured or rubbing alcohol mixed with water. You will need equal parts of water and alcohol. 50/50
- Blow Dryer •A Squeegee (That is provided with YourBoardWrap.com purchase) •Window Cleaner
- Single edge razor blade (An exacto blade is easier to use if you have one.) •2" masking tape (for hinge)

Prepping Your Board

Pull off any stickers with the heat of a blow dryer if needed. Then remove glue with the 50/50 Alcohol and water mixture. The goal is to have your board squeeky clean with no oils, glues or residues. Clean the board with Windex then your 50/50 Alcohol and water mixture again. Remember (Squeeky Clean)

1. Hold your graphic over the top of the board to place your graphic for position.

2. Tape across center (hinge).

3. Lift up left side hold vinyl in hand, then pull off the paper to the tape hinge. Cut the paper so you have the vinyl in your hand. Squeegee from the center out to the end of the board.

4. Repeat step 3 for second side of board.

5. Use a single edge razor or exacto blade to trim around the board. Just ride the edge of the board as a guide. Use caution not to slice into board edge. Try to ensure that there are no overhangs left as this could lead to slight edge peel. *Hint: When you are running around your board with a blade, be careful of your edges as they are very sharp.**

YOUR EDGE SHOULD LOOK LIKE THIS:



6. Apply hair dryer to entire surface and edges of YourBoardWrap until it feels warm to the touch. Apply pressure again, allow board to cool and then check adhesion around edges for a tight seal. Trim the areas that are not stuck.

7. Feel for the binding holes, make a single slice and re-install your bindings.

8. Feel free to call us if you have any questions while installing

IMPORTANT
When trimming, trim inside edge as to not leave any over hanging edges.
The snow can catch on and tear the boardwrap.



Finished Product!

